


ITE-12SD Quick Reference

2301-004

These procedures are written for Speaker use. You can use the handset for any step that requires using the Speaker button.

On a multi-line phone, when using a line other than your main extension, first press the button of the extension that you want to use. Then press the Speaker button or lift the handset.



Phone Features

You can adjust the ringer volume when receiving a call, or you can activate the ringer and adjust the volume.

Ringer Volume	Activate ringer and adjust volume	Press SPKR Or Lift handset	Speaker lamp on + Hear dial tone
		Press # * 1 1 2	Ringer activated
		Press SPKR	Phone rings
		Use the ringer control knob on the left side of the phone to adjust the volume	
Cancel Ringing	Press SPKR Or Lift handset		
	Press SPKR Or Hang up		Ringing cancelled

Adjusts the speaker volume while in conversation with another party.

Speaker Volume	Adjust the speaker volume	Place or receive a call using the speaker button	
		Use the speaker volume control lever on the right side of the phone to adjust the volume	

Phone Features

Display Screen	Condition	Display
	The phone is idle	11/21/02 2:03pm
	You dialed an inside number	8278 11/04/02 1:22pm
	You dialed and are connected to an outside number (shows the estimated cost of the call)	410-555-8888 2:49 \$ 1.50 4:25pm
	You received an inside call	SMITH JOHN FOR JONES MARY 1:30pm
	You received an outside call	(Name or Number) for JONES MARY 10:44am

The Display Button

- You can view stored numbers and names for Abbreviated Dial, Auto Dial, Callback, Forward, and Redial with the DSPL button
- The DSPL lamp must be on to use the feature
- The Display feature stays active as long as you press feature buttons. It automatically turns off 5 seconds after you press the last feature button.

Feature	Action	Display
Call Waiting	When call is ringing in: Press DSPL	SMITH JOHN FOR JONES MARY 1:30pm
Abbrev Dial numbers	Press DSPL + ABRV DIAL	0. 914107245555 11/21/02 2:03pm
	Repeat Until all numbers display	1. 99727278888 11/21/02 2:05pm
Auto Dial Numbers	Press DSPL + AUTO DIAL	ADL 914105555555 11/04/02 1:22pm
Name or number of a Callback sender	Press DSPL + CALL BACK	CALLBACK 11/21/02 2:03pm
	Repeat Until the number is displayed	8138 SMITH JOHN 11/21/02 1:25pm
		8555 JONES MARY 11/21/02 10:10am
A Callback with time stamp activated on the system	Press DSPL + CALL BACK	8138 SMITH JOHN 11/21/02 2:09pm
	Pause Until the date and time is displayed	AT:9:35am 11/21/02 11/21/02 1:25pm
A Call Forward number	Press DSPL + CALL FWRD	FORWARD 11/22/02 10:22am
		FWD 8138 11/22/02 10:22am
The last outside number dialed	Press DSPL + REDL	RDL 912104445555 11/22/02 1:22pm

Special Feature Buttons

Speaker	Place or answer calls/use features	Press SPKR	Speaker and Line Select lamps on + Speaker activated
	Switch from handset to speaker	Press SPKR	Speaker and Line Select lamps on + Speaker activated
		Hang up handset	
Switch from speaker to handset	Lift handset		Speaker lamp off and Line Select lamp on + Speaker deactivated

You can hear the other party, but the other party cannot hear you.

Mute	Mute the speaker	Press MUTE	Mute lamp on
	Talk with the other party again	Press MUTE	Mute lamp off
		Hang up handset	



Address comments to:

EADS Telecom North America
Technical Publications Manager, M/S 5A
Liberty Plaza II
5057 Keller Springs Rd.
Addison, TX 75001

Phone: 972.855.8000
Email: techpubs@eadstelecom-na.com

Other Feature Buttons

Other Features

Before using these features, read the following:

- These instructions are written for speaker use. You can use the handset for any step that requires pressing the speaker button.
- When using a line other than your main extension, press that line button before pressing the speaker button, or before lifting the handset.
- A fast busy tone heard when trying to use a feature generally means that the feature is not set up on your phone. See your system administrator.

Store up to 10 frequently called inside or outside numbers for quick dialing; up to 28 digits each

Abbreviated Dial	Store Abbrev Dial numbers	Press ABREV DIAL	Hear Dial Tone + Lamp Off
		Press *	Hear Silence
		Dial Storage Number Digit (0-9)	Hear 1 BEEP
		Dial Abbreviated Dial Number + access number for outside line	Hear 2 Beeps + Number is stored
Display stored numbers	Press DSPL + ABREV DIAL		0. 914107245555 11/21/02 2:03pm
	Repeat Until all numbers display		1. 99727278888 11/21/02 2:05pm
Place a call using Abbrev Dial	Press ABREV DIAL + Abrv code number (0-9)		The number is automatically dialed

Store one frequently called number on a feature button for quick dialing

Auto Dial	Store an Auto Dial Number (up to 28 digits)	(The phone is on hook) Press AUTO DIAL + Complete phone number including access codes	The number is stored
	Display an Auto Dial Number	Press DSPL + AUTO DIAL	ADL 914105558888 11/04/02 1:22pm
	Call an Auto Dial Number	Press SPKR + AUTO DIAL	The number is automatically dialed

Other Feature Buttons

Call back	Leave a callback on busy/no answer	Press CALL BACK	Hear 2 Beeps
	Display a callback that was left for you	Press DSPL + CALL BACK	CALLBACK 11/21/02 2:03pm
		Pause	See time and date (if option is activated on your system)
	Repeat	CALL BACK Until all numbers are displayed	AT:9:35am 11/21/02 1:25pm
Return a callback	Press CALL BACK	The callback is returned	
Return a callback when there is more than one	Press DSPL + CALL BACK	CALLBACK 11/21/02 2:03pm	
	Repeat	CALL BACK Until you see the number that you want to call	8138 SMITH JOHN 11/21/02 1:25pm 8555 JONES MARY 11/21/02 10:10am
	Then Immediately	Press SPKR + CALL BACK	The callback is placed
Display and Cancel a selected callback	Press DSPL + CALL BACK		
	Repeat	CALL BACK Until you see the number	8138 SMITH JOHN 11/21/02 2:09pm
	Pause	See time and date (if activated on your system)	AT:9:35am 11/21/02 1:25pm
	Press CANCEL	8138 **CANCELLED** 11/21/02 2:03pm	

Call Forward	Forward calls	(Forward each extension separately)	Hear 2 Beeps
	Press CALL FWRD		Hear 2 Beeps +
	Dial	Call Forward Number	Call Forward lamp on
	Cancel forwarding	Press CALL FWRD	Call Forward lamp off

Cancel	Cancel a call (Used with transfer, conference, and callback)		
	Cancel any call	Press CANCEL	

Do Not Disturb	Incoming calls are blocked. You can still place calls.		
	Block incoming calls	Press DO NOT DISTURB	DND lamp On
	Deactivate Do Not Disturb	Press DO NOT DISTURB	DND lamp Off

Other Feature Buttons

Call Park	Parks a call at a system-provided extension number. The call can be picked up from any phone in the system.		
	Park an active call	Press CALL PARK	Hear the Call Park number
		Write	Write down the Call Park number
	Hang Up		
Pick up a parked call from any phone in the system	Press SPKR		
	Dial	Call Park number	The parked party is on the line

Call Pickup	Answers a call that is ringing on another phone. There are two types of Call Pickup: Group Call Pickup and Extension Call Pickup		
	Pick up a call	As a member of a Call Pickup Group: Press CALL PICKUP	The call is picked up
	Pick up a call	By dialing the extension number: Press CALL PICKUP	
		Dial	Extension number

Call Waiting	A short ring heard during an active conversation indicates that there is a call waiting. The following shows you how to use the call waiting feature with both Normal Hold and Call Hold.		
	Accept a Call Waiting (Call Hold)	Press HOLD	Line lamp blinks + Phone rings
		Press SPKR	You are connected to the waiting party
	Return to the call on hold (Call Hold)	Press HOLD	You are reconnected to held party
Accept a call waiting (Normal Hold)	Press HOLD	Line lamp blinks + Phone Rings	
	Press SPKR	The waiting party is on the line	
	Return to holding party	Press SPKR	The first party is on the line

Buzz/Status	Place a direct call on a Buzz or Status line	Press BUZZ Or STAT	
		Press SPKR	The call is placed
	Answer a direct call	Press BUZZ Or STAT	
		Press SPKR	The call is answered

Other Feature Buttons

Conference	Conference up to 7 parties (Can include up to 4 outside calls)		
	Set up a Conference (Start from an existing call)	Press CONF	Hear Dial Tone
		Dial	Next Party → Announce Conf
	Press CONF	The party is joined into conference	
	Dial	Next Party → Announce Conf	
	Repeat	Until all parties are joined in conference	
Cancel a call to rejoin the conference	Press CANCEL Or CONF		
Put the conference on hold, or return to the conference	Press CONF	(Note: The hold button does not put the conference on hold)	

Hold	There are two types of hold: Call Hold - Hear dial tone when you put a call on hold Normal - Hear silence when you put a call on hold		
	Place a call on hold (Call Hold)	Press HOLD	Hear dial tone + Line lamp blinks
		Hang up	Or Dial another number
	Return to the call on hold (Call Hold)	Press SPKR Or Lift handset	You are reconnected to held party
		Press HOLD	
	Place a call on hold (Normal Hold)	Press HOLD	Hear silence + Line lamp blinks
Hang up			
Return to the call on hold (Normal Hold)	Press SPKR Or Lift handset	You are reconnected to held party	
	If you did not hang up the handset, choose the line where the lamp is blinking: Press LINE SELECT		

Intercom	Place an Intercom call	Press INCM	
		Press SPKR	
		Dial	Intercom Group Number
	Answer an Intercom call	Press INCM	
	Press SPKR	The call is answered	

Other Feature Buttons

Redial	Display the last outside number dialed	Press DSPL + REDL	RDL 912104445555 11/22/02 1:22pm
	Redial the last outside number	Press REDL	The number is redialed

Transfer/3-way Conference	Transfer an existing call to another destination			
	Transfer an existing call	Press XFER	Hear dial tone	
		Dial	Phone Number	
		Hang up Or Announce the transfer	Unannounced Transfer Announced Transfer	
	Cancel a Transfer	Press CANCEL	Transferred party is on your line	
		Or, after called party hangs up: Press XFER	Transferred party is on your line	
3-way Conference	Press XFER	Transfer lamp on		
	Dial	Phone Number		
	When party answers, announce the conference, then: Press XFER	Transfer lamp off + Conference lamp on		

Voice Mail	Your voice mail lamp flutters when you have a message in your voice mailbox		
	Access the voice mail system	Press VOICE MAIL	The voice mail system answers
		Follow the voice mail system prompts	
Access voice mail from another phone or outside location	Dial	The voice mail access number (provided by the system administrator)	The voice mail system answers
	Follow the voice mail system prompts		

